

# Calibration Log

Date Used	Recalibration Date	Notes

# AlcoHAWK® Precision Quick Guide

Be sure to read the entire owner's manual and follow procedures carefully to obtain optimal results.

## Operating Instructions

WAIT 20 MINUTES AFTER SMOKING, EATING, OR DRINKING BEFORE USE. FAILURE TO DO SO CAN ALTER THE BAC READING AND CAN DAMAGE THE SENSOR. USE ONLY 9 VOLT ALKALINE BATTERIES.

- 1) Insert a **NEW MOUTHPIECE** each time you perform a test.
- 2) If it has been more than 24 hours since the device was last used, **PRIME THE SENSOR** by blowing into the mouthpiece for 4 to 5 seconds before turning on the device.
- 3) **PRESS** the **Power On/Off** button. A single beep will sound and a green lamp will light below the PWR sign on the LED display. A yellow lamp will blink below the RDY sign on the LED display.
- 4) **WAIT** until the **YELLOW LAMP STOPS BLINKING** and remains on, and you hear a **SINGLE BEEP**. The device is now ready for use.

**Note:** The device will not shut off until a test is performed or until 15 seconds of non use elapses.

- 5) Take a **DEEP BREATH AND BLOW STEADILY** (for at least 5 seconds) until a **BEEP** sounds to signal completion of the testing.

**Note:** The unit will display a 0.000 after approximately 1 – 2 seconds if a trace level of alcohol is not detected in the breath sample (i.e., at least 0.001% BAC).

- 6) **SEE OWNERS MANUAL FOR HELP UNDERSTANDING THE RESULTS, ERROR MESSAGES AND PRECAUTIONS**

- 7) For more testing, wait one (1) minute and repeat steps 1 – 6.



**THIS DEVICE IS INTENDED TO MEASURE ALCOHOL IN THE HUMAN BREATH.**

**DO NOT DRINK AND DRIVE.**

**SEE OWNER'S MANUAL FOR RE-CALIBRATION INSTRUCTIONS THAT MUST BE PERFORMED AT LEAST EVERY 6-12 MONTHS.**